

### **DESCRIPTION**

Morganite manufactures a full line of accessories to complement its extensive crucible range.

#### **PRODUCT RANGE**

#### **Crucible Accessories:**

- Crucible Stands
- Muffle Rings (rings increase the cold charge capacity of the crucible and can improve melt times)
- Crucible Covers
- Spouts and Spout Extensions
- Crucible Lifters

# Foundry Products\*:

- Hot Rod Pyrometer Sheaths
- Launders and Tubes
- Ladle Bowls
- Degassing Tubes
- Plunger Mixers and Plunging Bells
- Cements and Castables
- Plates and Tiles
- Needle Valves and Nozzles/Down Spouts

\*Detailed information on these products is available by request

#### **APPLICATIONS**

Excel E stands and muffle rings are used in conjunction with Excel E and Iso-Alustar crucibles for aluminium alloy and zinc applications in electric resistance and gas-fired furnaces.

EXCEL stands and muffle rings are used in conjunction with Excel, Hi-Melt and Ultramelt crucibles intended for copper alloy and precious metal applications in gas and oil-fired furnaces.

SALAMANDER crucible accessories are available as spout extensions to increase pouring length and covers to exclude impurities from the melt. In addition a comprehensive range of graphitic Foundry products are offered in the form of both shaped and packaged refractories. We also supply crucible lifting devices.

#### TYPICAL METAL CASTING TEMPERATURE

Excel E Accessories: 650 - 1000°C (1202 - 1832°F) Excel Accessories: 900 - 1400°C (1652 - 2552°F) Salamander Accessories: 1000 - 1600°C (1832 - 2912°F)

#### PERFORMANCE CHARACTERISTICS

- Optimised glaze coatings tailored for specific temperature ranges
- Excellent thermal conductivity and shock resistance
- High resistance to oxidation
- Good wear resistance
- Good resistance to corrosive attack by chemical treatment agents
- Consistent performance
- High refractoriness
- Non-wetting properties


# **QUALITY**

Crucible accessories are manufactured from premium grade raw materials to the same ISO9000:2000 quality standards as our crucibles.

#### SAFETY

Proper safety clothing must be worn at all times. Ensure that no moisture is introduced into the melt and that all refractories and tools are dry before coming into contact with molten metal. Provision should be made underneath the furnace to catch metal that may be discharged.








**↑** HT

EXCEL / EXCEL E	STANDS				
XRX/XRX_E	TOD (mm)	BOD (mm)	HT (mm)	Spigot	Туре
XRX135	150	150	60		1
XRX138	200	200	75		1
XRX358	200	200	150		1
XRX155	250	250	50		1
XRX175	250	250	75		1
XRX102	250	250	100		1
XRX732	250	250	150		2
XRX739	250	250	250		2
XRX735	250	250	75	Υ	3
XRX1105	250	250	125	Υ	3
XRX104	250	250	250	Υ	3
XRX141	250	200	125		4
XRX356	250	200	175		4
XRX369	250	200	200		4
XRX0904	250	200	125	Υ	5
XRX0905	250	200	150	Υ	5
XRX530	250	200	175	Υ	5
XRX2610	300	300	200		2
XRX2611	300	300	300		2
XRX1205	300	300	125	Υ	3
XRX1407	300	300	175	Υ	3
XRX2612	300	300	300	Υ	3
XRX800	315	245	150		4
XRX177	315	245	175		4
XRX737	315	245	200	Υ	5
XRX165	320	250	100		4
XRX132	320	250	125	Y	4
XRX1306 XRX731	320 320	250 250	150 200	Y	5 4
XRX166	320	250	250		4
XRX320	350	320	50		4
XRX402	350	350	60		1
XRX401	350	350	75		1
XRX804	350	350	120		1
XRX300	350	350	100		2
XRX100	350	250	100		4
XRX202	350	250	125		4
XRX500	350	250	160		4
XRX412	350	250	175		4
XRX200	350	250	200		4
XRX1500	350	250	250		4
XRX146	381	381	51		1
XRX247	381	381	100		2
XRX145	381	381	115		2
XRX350	381	381	350		2
XRX1405	381	381	115	Υ	3
XRX760	381	300	215		6
XRX425	425	425	50		1
XRX2632	425	425	75	Υ	3
XRX2471	425	425	100		2
XRX263	425	425	115	V	2
XRX2634 XRX2473	425 425	425 425	115 125	Y	2
XRX2473 XRX2474	425	425	150		2
XRX2474 XRX2475	425	425	150	Y	3
XRX1100	425	425	170		2
XRX2472	425	425	200		2
XRX587	425	300	215		6
Spigot dimensions: Heigh					



EXCEL / EXCEL E	MUFFLE	RINGS		
XRX/XRX_E	TOD (mm)	BOD (mm)	HT (mm)	
XMX71	350	350	280	
XMX122	415	415	255	
XMX159	527	516	305	
XMX143	616	615	203	
XMX302	616	616	90	

666

775

305


240

680


775

XMX102

XMX162



SALAMANDER	STANDARD	COVERS	
хо	TOD (mm)	HT (mm)	
XO1	75	29	
XO3	97	32	
XO5	114	38	
X06	135	44	
XO8	149	48	
XO14	173	51	
XO20	184	57	
XO30	221	60	
XO40	245	65	
XO60	257	67	
XO102	273	70	
XO90	286	68	
XO100	317	73	
XO22R	317	76	
XO101	317	41	
XO130	336	84	
XO170	365	89	
XO250	413	108	
XO300	445	140	
XO545	550	40	
XO616	616	75	
XO587	775	75	
XO850	850	75	
CALAMANDER	TILTED COV	/EDC	



SALAMANDER TILTER COVERS						
хо	TOD (mm)	BOD (mm)	H1 (mm)	H2 (mm)		
XO275	279	222	29	42		
XO279	324	267	25	19		
XO298	381	248	32	44		
XO280	394	330	25	19		





# **SPOUT EXTENSIONS**

Pattern (XU/XUX)	A (mm)	B (mm)	C (mm)	D (mm)	E (mm)	F (mm)	G (mm)	H (mm)	l (mm)
XUX700*	205	76	38	38	76	111	38	76	152
XU121**	292	62	35	44	83	129	89	102	171
XU982*	400	76	38	38	76	111	38	76	152
XU984*	450	76	38	38	76	111	38	76	152

<sup>\*</sup>Use with TP spouted crucibles

<sup>\*\*</sup>Use with TE spouted cylindrical crucibles

# CRUCIBLES TO MEET EVERY APPLICATION



**EXCEL, HIMELT** 



Roller-Formed SIC



INDUX Clay Graphite



ISO-ALUSTAR ISO-Pressed Clay Graphite



SALAMANDER SUPER



ULTRAMELT

# **CRUCIBLE CARE**



Store crucibles off the floor in a dry, warm place.



Do not nest one inside another. Separate layers with hardboard.



Do not roll crucibles. Move using a sack truck with padding.



Check thoroughly for cracks or damage before use.



Use the correct crucible stand which must be central and support the whole base.



Allow space for expansion between crucible and furnace lining/cover.



Use correctly positioned grip bricks in tilting furnaces, leaving gaps for expansion. Do not hang crucible on spout.



The flame path must be tangential to the crucible.



Ingots should be loaded carefully into the crucible using tongs.




First charge with light returns, as a cushion, then add ingots vertically.



Only add flux after the metal is molten.



Avoid ingress of cold air by ensuring that the drain hole is sealed.



Lift-out tongs should hold crucible on it's lower third and fit evenly on both sides.



The crucible must be emptied before switching off the furnace.

DISTRIBUTED BY



The crucible should be cleaned out carefully every day while still red hot.



MORGANITE CRUCIBLE LTD

